

MOTIVATION




- Residual stress widely exists in the thin-film material (metal, semiconductor and dielectric) layers used in IC manufacturing.
- The residual stress can significantly impact the device behavior, performance, reliability and manufacturability.
- Fast and accurate characterization of residual stress is critical for the stress control and optimization of the fabrication process.

HYPOTHESIS

- Residual stress is contributed by a large number of factors, which can be either compressive or tensile.
- When deposited on one side, the residual stress in the thin film can cause bending or warpage of the supporting substrate.
- The overall residual stress and its spatial distribution can be characterized by the local curvature of the substrate.

RESULTS

- Substrate: 200- μm {100} single-crystal silicon wafer
- Deposited thin film: 200-nm SiO_2 with PECVD
- Wafer curvature measurement: Bruker Dektak[®] Surface Profiler



DISCUSSIONS

- Average stress level: -123.8 MPa
- Standard Deviation of 0.0183 MPa
- Negative stress means the deposited film is under compression, which makes the substrate buckle up.
- Some variation between the parts of the wafer, but still fairly closely grouped across the surface of the wafer sample.



$$T_f = \frac{E_s h_s^2}{6 h_f R (1 - \nu_s)}$$

T_f - Residual Stress E_s - Substrate Young's Modulus
 h_f - Film thickness h_s - Substrate thickness
 R - Radius of curve ν_s - Poisson ratio of 100 Si crystal

CONCLUSIONS

- Wafer curvature measurements under a surface profiler can serve as a quick and effective way for non-destructive evaluation of residual stress in thin films.
- This method can be expanded for the investigation of different deposition conditions and different materials.

ACKNOWLEDGEMENT

We thank Samsung Austin Semiconductor for providing funding support for the fellowship and cleanroom access and also AggieFab Nanofabrication Facility staff for technical support in equipment training and usage.